

riag Oberflächentechnik AG Postfach 169 CH-9545 Wängi TG

07.09.2021

riag Clean 685

Soak degreasing process with high cleaning efficiency

The **riag Clean 685** is a degreasing process with an excellent cleaning performance, which is intended to be used for iron and steel.

Properties

- Liquid
- Suitable for steel and magnesium (depending on the alloy)
- Spraying possible above 40 °C
- Demulsifying
- Temporary corrosion protection
- Usable with tap water

Ingredients

- Amines
- Organic acid sodium salt
- Nonionic surfactants
- Anionic surfactants

Make up of riag Clean 685

	immersion cleaner	
riag Clean 685 Additive	10 –	40 mL/L
Temperature	40 –	80 °C
Time	1 –	10 min

The degreasing system already contains surfactants, usually no additional detergents are necessary. In case of degreasing problems, contact our sales department for the best solution.

Make up

The tank is filled to 2 / $_3$ with water. Add the calculated amount of **riag Clean 685 Additive** and stir well. Finally add water up to the working level. Once the cleaner has reached its working temperature, it is ready for use.

Page 1 / 3

Operating parameters

Agitation Recommended (shorter treating time), as it supports the cleaning

process

Tanks Plastic or lined steel, when using ultrasonic high alloy steel

Heating Immersion heaters, but thermostatic control is essential.

Fume extraction Recommended

Water To ensure the longest possible service life and trouble-free use, we

recommend the use of deionised water.

Maintenance

riag Clean 685 is used in different concentrations, due to the various possibilities of application. The concentration has to be checked after each make up by analysis to stay in the desired working range.

Environmental considerations

All concentrates, rinse waters and waste solution must be treated and discharged in accordance with local effluent control regulations. Further information can be gleaned from the MSDS. Chemicals may not be stored below 10 °C.

Liability

This instruction manual was compiled with reference to the state of the art and all current standards, and is based on the long-term knowledge and experience of riag. However, riag cannot monitor compliance with this instruction manual and the methods described herein at the customer/end-user's premises. Work carried out with riag products must be adapted accordingly to meet local conditions. In particular, riag cannot accept liability for damage, loss or cost incurred due to a failure to adhere to this instruction manual, improper application of the methods, unauthorised technical modifications, insufficient maintenance or the absence of maintenance in respect of the requisite technical hardware or equipment, or in the event of use by unqualified personnel. riag is not liable for damage or loss caused by riag or its employees except where intention or gross negligence can be proved. riag furthermore reserves the right to make changes in relation to products, methods and the instruction manual without prior notice.

Our goods and services are subject to the General Terms and Conditions for Delivery of the Association of Surface Technology Suppliers (VLO), which can be viewed at www.riag.ch (link "terms and conditions", document "General Terms and Conditions for Delivery", version 3/2018), which we gladly send you on request.

This transaction is governed by material Swiss law (Law of Obligations), excluding private international law (conflict of laws) and intergovernmental treaties, specifically the CISG.

riag Oberflächentechnik AG Murgstrasse 19a CH-9545 Wängi T +41 (0)52 369 70 70 F +41 (0)52 369 70 79 riag.ch info@riag.ch

riag Clean 685 Page 2 / 3

riag Oberflächentechnik AG

Analysis (Analytical methods)

Sample preparation:

Take sample from a well-mixed location and allow to cool down to 25 °C.

Reagents: Hydrochloric acid 1 mol/L

Methyl orange solution 0.1 % in water

Procedure: 50 mL riag Clean 685 are transferred via pipette into a

250 mL beaker, add

50 mL deion. water, add

5 drops methyl orange solution

Titrate with hydrochloric acid 1 mol/L from yellow to red

Calculation: riag Clean 685 Additive (g/L) = use of HCl in mL x 9.0

Attention:

Chemicals not intended to be added to the process may disturb and influence the quality of the processed surfaces.

riag Clean 685 Page 3 / 3